

**Instruction of use of the safety lock type ZZ-01
for coupling heads ZSK or BC**

Safety lock fixed correctly impede theft of the trailer.

Safety lock ZZ-01 matches Steelpress coupling heads. For ZSK coupling heads it can be used both for the hooked and not hooked trailer. For BC coupling heads ZZ-01 can be used for hooked trailer only.

In order to use ZZ-01 correctly you need to:

- move down the ZSK coupling head lever
- take the bolt out of ZZ-01,
- put the safety lock on the coupling head (inscription FRONT to be seen at the front),
- put the bolt into the possibly higher hole of ZZ-01,
- put the padlock on the hole in the bolt

STEELPRESS Sp. z o.o.

ul. Powstańców Wielkopolskich 48 62-031 Luboń – Poznań, Poland

Index_01_2012_01_27